

PROTECTION AT A HIGHER LEVEL®

GET THE BEST OUT OF YOUR PRODUCT

STORING YOUR ARMOR ATTACHMENTS

Proper storage and frequent inspection of your Armor Attachments can help you maintain their life and performance. Once the attachments are removed from their packaging, care should be taken to store them flat — either on a shelf or other flat surface. When this is not practical, suspending them on a clothes hanger is the next best method. **Armor Attachments should never be stored folded, compressed, or stood on their edge.** This improper storage may create permanent creases or cause curling at the edges.

Store your Armor Attachments at room temperature as often as possible. **Never store them in places where temperatures exceed 130-150°F, such as a trunk of a vehicle.** Excessive heat may compromise the integrity of the materials and affect performance specifications.

It is important to note that improper storage of your Armor Attachments may void the warranty.

CLEANING YOUR ARMOR ATTACHMENTS

Clean each component of your Armor Attachments separately and NEVER as a complete system.

CLEANING YOUR ARMOR ATTACHMENTS

Before cleaning, remove armor from each attachment. Each component — including groin, low ab, bicep, throat, neck/upper shoulder attachments — should be cleaned separately.

CLEANING ARMOR ATTACHMENT COMPONENTS

Remove the armor panels before cleaning. Gently wipe each component with a damp sponge or microfiber cloth using cold water and a mild laundry detergent if necessary. After cleaning, lay the attachment flat and wipe dry. Straps, loops, and fabric components may be cleaned in the same manner.

ARMOR PANEL LAUNDRY TIPS

 DO NOT IMERGE IN LIQUID	 DO NOT MACHINE WASH
 DO NOT USE BLEACH	 DO NOT TUMBLE DRY
 DO NOT DRY CLEAN	 DO NOT EXPOSE TO EXTREME HEAT

GENERAL LAUNDRY TIPS

 DO NOT USE CITRUS BASED CLEANERS	 DO NOT IRON
 DO NOT USE BLEACH	 DO NOT TUMBLE DRY
 DO NOT DRY CLEAN	 DO NOT WASH WITH HOT WATER